

Programming Manual



BFT Clonix 2E





Assembly of your receiver

- 1. Open the casing of your receiver.
- 2. On the receiver circuit board, press the SW1 button. Let it go. The Led light of the receiver blinks.
- 3. Press both buttons on your new remote control (both superior buttons if your remote control has 4 buttons) until the LED light of the receiver illuminates fixedly.
- 4. Press the first button on your new remote control until the LED light of the receiver blinks again.
- 5. The Led light of the receiver turns off.
- 6. The first button of your new remote control is programmed.
- 7. Repeat this procedure to program the second button of your new remote control. Use this time the SW2 button on the circuit board of the receiver.